

Frequently Asked Questions about Epocast

Epocast:

- What is the minimum required hardness for:
 - EPOCAST 36®: Barcol Hardness: min. 40
 - EPOCAST 36-P: Barcol Hardness: min. 30
 - TG7B Paste: Barcol hardness: 30-34 Barcol
 - TG7B Liquid: Barcol hardness: 40-50 Barcol
- What are the limits in chock heights, lengths, and widths?
 - See TDS/TBS/Handbook:
 - EPOCAST 36®: 12 mm – 100 mm
 - For exceptions please consult Technical Service
- Could you support us to calculate the required quantity of Epocast?
 - We recommend the following for calculations:
 - EPOCAST MARINE Handbook
- What are the required accessories and where can we purchase these?
 - Chocking products:
 - Barcol Tester 934-1 / Barcol Test shims 43-48
 - Release Agent: <https://www.gebr-barth.de/>
 - Foam Rubber <https://www.gebr-barth.de/> or
 - Global Alignment <http://www.globalalignment.de/>
 - CELLOFLEX-M:
 - Primer S <https://www.gebr-barth.de/> or Euroteam <https://www.euroteam-bauchemie.de/>
 - Cleaner from <https://www.gebr-barth.de/>
 - 100 m Glass silk tape Rowing 10 cm / wide <https://www.gebr-barth.de/>

General Questions

- Where can I find a Safety Data Sheet for one of your products?
 - <https://itwperformancepolymers.com/data-sheets/safety-data-sheets>
- Do you have more detailed product information available, such as mix ratio, operating temperatures, and application instructions?
 - These can be found in our Technical Data Sheets, which are available at <https://itwperformancepolymers.com/data-sheets/technical-data-sheets>
- Where can I get pricing information or purchase one of your products?
 - Please contact one of our distributors, which can be found at <https://itwperformancepolymers.com/distributors>